

Quick Start Guide: iOS Iridium[®] Mail & Web app and Iridium AxcessPoint

iOS Iridium Mail & Web app and Iridium Mail & Web mobile application are available for download on the Apple iOS App Store[™]. This quick start guide provides step-by-step instructions for configuring Iridium Mail & Web application and its various features to work with Iridium AxcessPoint.

1) Download Iridium Mail & Web app

While connected to a Wi-Fi network (recommended) or a terrestrial cellular network with data connection, search for 'Iridium Mail & Web' in iTunes app store. Download and install the app on your iPhone[®] or iPad[®] running iOS 6.1 or higher.

2) Register for an Iridium account

Navigate to <u>www.iridium.com/mailandweb</u> URL to fill out the registration form, follow the instructions and register for a username and password. Select 'Iridium AxcessPoint' from the device selection drop-down menu in the registration form. Registration for an account is free and required to use the application.

- 3) Pair the iOS device with Iridium AxcessPoint
 - i. Connect your Iridium AxcessPoint to your Iridium satellite phone with the provided USB cable.
 - ii. Set up the phone in an outdoor area with open access to the sky and adequate signal strength prior to use.
 - iii. Turn your Iridium AxcessPoint device switch to "On" when attempting to establish a Wi-Fi hotspot.
 - iv. Go to "Settings" on your iOS smartphone or tablet
 - v. Select "Wi-Fi".
 - vi. Under "Choose a Network", select "PHS300IC-xxxx". Wait for your iOS device to connect to the Iridium AxcessPoint Wi-Fi network.





4) Login to the application

Open the Iridium Mail & Web app. You will be asked to enter the registered username and password. Enter the credentials as supplied during registration and click on 'Login' to gain access to the application. Accept the terms and conditions outlined in the End User License Agreement popup. This dialog is displayed only on the initial user login.

Required		
Required		
Veb Account a m.com/mailan	it dweb, tl	nen
Ok		
	Required ccount Conf for an Iridium Veb Account a n.com/mailand equired inform	Required ccount Config for an Iridium Mail and Veb Account at n.com/mailandweb, th equired information he

5) <u>Configure device connection type</u>

After logging in to the application for the first time, the app will guide you to configure the device connection type. Click OK to be redirected to the device selection screen. Select 'Iridium AxcessPoint' as your connection type and click the back button. Alternatively, you can run the device auto-detection capability by selecting 'Detect Device' button.

Note: Ensure that the 'Diagnostics' is turned off. This is an advanced option and is used Iridium support personnel to troubleshoot device connection & detection issues with the user.

mil.AT&T रू 9:29 AM 74% ■). Iridium	ntl. AT&T 후 4:11 PM 91% 📼 Settings
···· iridium	
Additional Configuration Needed You need to select your connection	Iridium AxcessPoint Iridium GO! for mobile devices
type next. OK	RedPort Aurora
MAIL WEB PHOTOS	Detect Device Modify Configuration
	Diagnostics OFF






6) Configure Web surfing

Iridium Mail & Web allows you to surf the web. To access web pages via Iridium Mail & Web, follow these instructions:

- a. Select the Web icon on the home screen.
- b. Follow the instructions outlined on the screen to enable compression and setup a proxy server.



To access web pages using Iridium Mail & Web:

- i. Click on the 'Web' icon on the home screen
- ii. Click the upper-right "Connect" option to start your connection
- iii. Launch Safari browser, enter a mobile website and press "Go" (see <u>www.iridium.com/mobile</u> for list)
- iv. Continue to access Web content. When finished, close Safari browser and return to the Iridium Mail & Web app.
- v. Click the "Connection" icon on the main Web screen and stop the data connection

Note: Airtime charges will continue while the connection is active. Do not visit standard Internet pages as videos and graphic-heavy pages designed for broadband networks will not download properly using Iridium Mail & Web.

7) Configure Social Media settings (Facebook)

Facebook is a great way to update many people with the push of a single button. Most people post to Facebook from the Facebook page, which is too large for handheld satellite phones to conveniently update. Configuring Wireless Email Gateway for Facebook allows simple posts to Facebook by converting your message into an email format that Facebook will accept and post. You can even upload photos. They will be resized, compressed, and posted at a size that works over handheld satellite phone data feeds. Broadband users can also upload video.

A. Activate Facebook Posting: Requires a Post-by-Email Address, assigned to you by Facebook. You also must link your cellular phone number to your Facebook account. To find your Post-by-Email Address:





- i. Open a web browser, and go to: <u>www.facebook.com</u>
- ii. Sign into your Facebook account.
- iii. Click on the $\overset{\textcircled{}}{\overset{}}$ in the top right corner of the screen.
- iv. Click "Account Settings"
- v. Click "mobile" in the left column
- vi. Click "Add a mobile phone number"
- vii. Type in your Facebook password
- viii. Select your country and you cellular phone number.
- ix. Follow on screen instructions. Facebook will text you a code to your phone to put in the box in the Facebook window.
- x. After your phone is linked to your Facebook account, you will find your "Post-by-Email Address" on the mobile section of the account settings.
- xi. Copy or write down the address.
- xii. Enter the Post-by-Email Address by selecting the Settings icon on the home screen and navigating to Social Media > Facebook > Secret Email. Then click <OK>. Notice that the Facebook icon on the user interface is now active.

и AT&T 穼	9:32 AM	70% 🛤
Back S	ocial Medi	а
Facebook:		
Secret Email:		
Go to F	acebook to g	et Email
Twitter	OFF	

B. Posting to Facebook

- i. Click the Facebook icon on the home screen to open the "Post to Facebook Wall" window.
- ii. Enter the status update (maximum of 255 characters) in the text box.
- iii. To upload a photo, click the <Browse> button and select the image to upload.
- iv. Click <OK>. This creates a message ready to be sent on your next connection.
- v. The posting will be sent the next time you make an email connection.





8) <u>Configure Social Media settings (Twitter)</u>

- i. Connect to the internet at home before going on your trip. Twitter registration will fail if you are not connected to the internet.
- ii. Click on the Settings icon on home screen, select 'Social Media' and turn on Twitter
- iii. A window will appear asking you to login to Twitter to allow Iridium Mail & Web to post on your behalf

AT&T 🛜 9:32 AM	70% 🛤	ш AT&T 穼	2:57 PM	
ncel Sign In		Enter PIN		
Get a PIN from Twitte	er →	y	Sign u	o for
Tap on the link to go to Twitter's we and get a PIN. Memorize or copy it This app will not see your Twitter lo	L.		Iridium Mail a r account?	nd
2 Type the PIN below.		By Irid	m Mail and Web ium Communications ridium.com	Inc.
			will be able to:	
Sign In		 See who you 	s from your timeline a follow, and follow i	
		Update yourPost Tweets		
		Username or	email	_
		Password		

- iv. Allow Iridium Mail & Web access to your Twitter account
- v. A PIN will be generated once authentication has been granted. Record the PIN.
- vi. Enter the PIN in the appropriate location and hit OK.

Once this configuration is complete, tweets can be posted via Iridium Mail & Web using the Twitter icon on the home screen.





9) <u>Configure weather forecast service</u>

The application provides various user-customizable settings for the weather forecast service. To configure these settings

- i. Click on Settings icon on the home screen
- ii. Click on 'Weather'

ыц AT&T 穼	9:32 AM	70% 🛤
Iridium		
John Doe		>
Connection	ı	>
Server		>
Images		>
Social Med	lia	>
Weather		>

iii. Set locales: allows you to request weather information for different locations.

ш AT&T 穼	9:33 AM		70% 🖾
Back Weat	her Set	tings	Edit
Locations (1)			>
Display Frequency	1h	3h	6h
Use GMT		\bigcirc	OFF
Duration (Days)			
Days	3 4	5	6 7
Units			
Temperature	°C		°F
Pressure	mbar		inHg
Height/Distance	m		ft






You can either save current location, enter latitude\longitude coordinates manually or select from a list of approx. 9000 airports worldwide

a. Click on 'Locations'

ull. AT&T 🗢	2:25 PM	96% E
Weather Settings	Stations	+
Current Location		ON

- b. To add a location, click on '+' button.
 - To save current location, click OK when prompted for "Iridium Mail & Web would like to use your current location"
 - 'Enter Location' option allows you to enter location lat\long coordinates manually in decimal format (ex. Lat: 40.76 N, Lon: 73.984 W) and add a name (ex. New York, NY). Other formats such as degrees minutes seconds, degrees decimal minutes are also supported. You can set the format in Weather settings.
 - Select airport: Search bar is provided to search for an airport either using the 3-letter airport code or by city name



c. Enter a user-friendly name





iv. Configure the display frequency, duration (days), units and types of various weather parameters to request forecast

L. AT&T 奈	9:33 AM	70% 🛤	• п. A	तक्षा 🗢	9:33 AM	70
Back Weat	her Settings	Edit	Ba	^{ck} Wea	ther Settir	ngs 🔲
Locations (1)		>	V	Veather Param	neters	
			Su	urface Temper	ature	ON
Display Frequency	1h 3h	6h	Su	urface Pressur	e	ON
Use GMT	C	OFF	M	ean Sea Level	Pressure	ON
Duration (Days)			w	ind Speed		ON
Days	3 4 5	6 7	w	ind direction		ON
Units			w	ave period		OF
Temperature	°C	°F		ave height		OF
Pressure	mbar	inHg		-		
FIESSUIE	mbal		lce	e pellets? (Y/N	1)	OFI
Height/Distance	m	ft	Vi	sibility		

- 10) Exit Settings and return to the home screen
- 11) You are now ready to use Iridium Mail & Web features.

For more detailed information on your Iridium GO!, please visit <u>www.iridiumgo.com</u>. Prior to using Iridium GO!, read and understand the User Manual including the safety warnings and information.

Only one communications company connects the entire globe

Iridium commands the world's furthest reaching network, making it the only truly global communications company with solutions that span from pole-to-pole. Iridium voice and data products provide superior communications solutions that allow global companies, government agencies and individuals to stay connected everywhere. With a unique, global ecosystem of partners, Iridium continues to create new, highvalue capabilities that are leading the world into a new era of communication.

www.iridium.com

Iridium and the Iridium logo are registered trademarks and Iridium GO! is a trademark of Iridium Satellite LLC. All other trademarks, service marks and logos are the property of their respective holders, which have not endorsed, sponsored or otherwise affiliated with Iridium. Android and Google Play are trademarks of Google Inc. Apple, iPhone, iPod and iPad are registered trademarks of Apple Inc. App Store is a service mark of Apple Inc. © Copyright 2014 Iridium Satellite LLC. All rights reserved.

iOS Iridium Mail & Web app and Iridium AxcessPoint

